

GRE AMERICA, INC.

Product: **PSR Series**

Classification: **Firmware Download Instructions.**

Date: **11/05/2007**

-
- 1) Download the Firmware to your local PC
 - 2) Execute (Double Click) the "**EXE**" file, you will be prompt with "**Unzip to Folder**" >> "**C:\GRECOM**". Click "**Unzip**" icon on the upper Right Corner.
 - 3) If you are upgrading both the CPU and the DSP code, we recommend upgrading the **CPU** code first.
 - 4) Go to **C:\GRECOM** and execute (Double Click) the upgrade file you wish to execute.

***Note:** Prior to executing the upgrade files on your PC, you must ensure that you have properly installed and configured your USB PC/IF Scanner Data cable on your PC. You must also know the "COM" port that your USB PC/IF Scanner Data Cable has been assigned.*

You can check your USB PC/IF Scanner Data Cable COM Port assignment by:

- a) Clicking on "**Start**" > "**Settings**" > "**Control Panel**"
- b) Select "**System**"
- c) Choose the "**Hardware**" Tab
- d) Select "**Device Manager**"
- e) Double-click on "**Ports (COM & LPT)**". Within the expanded list, look for "**USB Serial Port (COM??)**" and note the COM Port number
- f) Run the GRE upgrade file
- g) Within the upgrade file step #2, set the COM port pull-down list setting to what was observed above within step (e) "**USB Serial Port (COM??)**"

Please feel free to contact us should you have any issues or need technical assistance at

GRE Development Team

© 2007. GRE America, Inc.

<http://www.greamerica.com/support>